






## PROFILE RAIL LINEAR ACTUATOR ORDERING GUIDE

PRA	-	8	S	_	025	N	_	10	_	E200	-	Α
Series	] -	Series Model	Motor Length	_	Lead Code	Nut Style	_	Series	_	Encoder	_	Encoder Position
PRA Profile Rail Linear Actuator		8 Single Stack Only	e		See Lead Code Table Pg. 3	<b>N</b> Standard Freewheeling Nut		Length (inch) example: <b>10.00</b> "		E 200 200 CPR		A
		11	Single Stack							<b>E 500</b> 500 CPR		В
										E 1000 1000 CPR		
		17	<b>D</b> Double Stack			A Axial Anti-Backlash Nut				E 2000		
										2000 CPR		<b>O</b> No Encoder Position
		23								<b>00</b> No Encoder		

We welcome custom projects. To speak with one of our linear motion project engineers, email us at engineeringhelp@helixlinear.com or call 1-855-435-4958.

## **ENCODER POSITION DIAGRAM**



HELIXLINEAR.COM